

SKIER TYPE

TYPE 1

Cautious skiing at **lighter** release/retention settings.

TYPE 2

Cautious skiing at **average** release/retention settings.

TYPE 3

Cautious skiing at **higher** release/retention settings.

SHOE SIZE CONVERSION CHART

US Children's Shoe Size	US Men's Shoe Size	US Women's Shoe Size	European Shoe Size
9.5			15.5
10.5			16.5
11.5			17.5
12.5			18.5
13.5			19.5
1.5			20.5
2.5			21.5
3.5		5.5	22.5
4.5		6.5	23.5
5.5	6.5	7.5	24.5
	7.5	8.5	25.5
	8.5	9.5	26.5
	9.5	10.5	27.5
	10.5		28.5
	11.5		29.5
	12.5		30.5
	13.5		31.5
	14.5		32.5
	15.5		33.5
	16.5		34.5